



ALL AMERICAN MONITORING

Programming Steps – SIMON XT

1. Press Down Arrow 4 times to System Programming, Press OK button,
Then enter installer code and press OK button.
2. Press Down Arrow, Press OK button, OK button again, Enter Account #, Press OK, Press Status.
3. Press Down Arrow, Press OK button, OK button again, Enter Receiver #, Press OK, Press Status.
4. Press Arrow Down 3 times to Reporting, Press OK button, Arrow Down 1 time, Press OK button,
Phone 1 Press OK button, Arrow Down 1 time until you select ALL CID then Press OK.
5. Press Status 4 times to Exit Programming.

Wiring the MN02-LTE Cellular Communicator and Programming the Panel

SIMON XT

