



# ALL AMERICAN MONITORING

## Programming Steps – LYNX PLUS

### Programming: Basic Communication

KEYPAD DISPLAY	ENTER ON KEYPAD	COMMENTS
Primary Phone Number	*41	Enter Primary Phone Number
Primary Account Number	*43	Enter Primary Account Number
Phone System Select	*47	Enter 1 For Tone Dialing
Reporting Format	*48	Enter 7, 7 For Contact ID Format
Split/Dual Reporting	*49	Enter 0 For All Reports
15 Sec Dialer Delay	*50	Enter 0 For NO Dialer Delay

## Wiring the MN02-LTE Cellular Communicator and Programming the Panel

### LYNX PLUS

